

## PACKING INSTRUCTIONS

### SINGLE BIKE BOX – 2 Track Frames

#### STEP 1:

REMOVE CHAINRING, PEDALS, SEATPOST (HEIGHT MARKED) HANDLEBARS. ALL PARTS SHOULD BE LABELED. USE VELCRO STRIP OR TAPE TO MARK HEAD STEM POSITION. PUT FORK BLOCK IN DROPOUT AND SECURE WITH ELASTIC STRAP LOOPED OVER FORK STEERER.



#### STEP 2:

PLACE PEDALS AND SEAT CLAMP IN POCKET OF REAR WHEEL BAG. PLACE WHEEL BAG OVER REAR WHEEL WHILE MOUNTED IN BIKE. PLACE SEATS INSIDE PROTECTIVE BAG/BUBBLE WRAP AND POSITION ON BOTTOM OF BOX WHERE THEY WILL BE HELD IN PLACE BY REAR WHEELS.



#### STEP 3:

PLACE BOTH BIKES IN BOX FACING OPPOSITE DIRECTIONS. REMOVE FRONT SKEWERS (OR SCREW IN WHEEL NUTS COMPLETELY) PUT IN POCKETS OF WHEEL BAGS. PUT FRONT WHEELS IN WHEEL BAGS AND PLACE BOTH WHEELS BETWEEN THE TWO FRAMES.



#### STEP 4:

PUT HANDLEBARS IN BAG OR BUBBLE WRAP AND PLACE INSIDE BOX. HOOKED AROUND REAR WHEEL AGAINST THE END OF THE BOX WORKS WELL. PUT LID ON BOX AND DO UP STRAPS. BOX SHOULD IDEALLY WEIGH NO MORE THAN 23KG

